


# Ecotec 937 Actostor fault finder

Carry out basic checks. i.e. Electrical safety, Polarity, Gas Working pressure. Etc.  
 Check for installation defects.  
 Gain information in order to replicate fault.  
 Make sure that the NTC's and other components are securely fitted in the correct position.  
**Check D.S.N. and all other factory settings.**

**Note:**  
 If a fault has been identified and corrected, you **MUST** perform a final 10 minute test of the Actostor recharge procedure to Verify correct operation.



# Ecotec 937 actostor code guide

## METHOD OF HOT WATER OPERATION WITH WARMSTART ON

When a hot tap is opened the aqua sensor puts the appliance into hot water demand mode. The diverter valve is driven into HW position, the shiftload pump is energised and ignition sequence starts. Incoming mains water is heated at the plate heat exchanger and transferred to the Actostor for hot water usage via the Shiftload pump. Hot water temperature is controlled from the left NTC measured at (D3).

When the hot water tap is closed the burner will stay lit and the shift load pump continues to circulate the water from the plate heat exchanger, through the Actostor and back, until the actostor target temperature (D6) is achieved at the Right hand NTC (No D code).

From the point at which the tap is closed and the aquasensor records no DHW flow (D36) this signals the start of a 10min time period for the actostor to reach target temperature. If this temperature is not reached the appliance goes into a fault status of F81/91.

This method is controlled by 3 thermistors on the actostor, the shiftload pump and the Actostor PCB. See figure 1.

The clip-on thermistor on the left is the DHW flow temperature (D3).

The clip-on thermistor on the right is the inlet temperature (No D code).

There is also a NTC situated at the centre of the Actostor, Tank temp (D4).

## Status codes

Provide information concerning the current operating status of the appliance. Press the "I" button and the display will show a status code eg S.24 if the burner is lit during DHW Reheat mode. (Consult installation manual for full list)

Press "I" again to return to the normal display.

## Components

The actostor unit consists of the following electronic components

Aqua sensor D36

Actostor pcb (see photo Left)

Tank charging thermistor (ntc) D3

Inlet sensor (ntc) No D Code

Storage tank sensor(ntc) D4

Shift load pump D12

Wiring harness

The majority of faults can be dealt with using the diagnostics and a multimeter.

The only logic link from the actostor pcb to the main pcb is plug X31 with 3 pins

The shift load pump takes 240vdc supply direct from plug X12 on the main pcb

## Diagnostic Levels

Diagnostic codes are used to display information such as sensor readings, component settings and parameters. Some are read only and others can be altered. There are 2 diagnostic levels.

### Level 1 Diagnostics

To access the 1st level press the "i" and "+" buttons simultaneously then the display shows "d.00". Using + or - move to the required diagnostic number, then by pressing the "i" button the set value will be displayed (display flashing) If necessary this can be changed by using the "+" or "-" then hold down the "i" button for approximately 5 seconds until the display stops flashing. To come out of the diagnostic mode press the "i" and "+" buttons simultaneously which takes you to the normal display.

### Level 2 Diagnostics

To access the 2nd level diagnostics you enter the first level and go to d.97 then press the "i" button, then change the value to 17 and push the "i" button. You will now be in the second level, which will also include the information from the first level. The same procedure is used to view/change values or leave this level. If you come back into the diagnostics within 4 minutes you will go directly to the 2nd level. A list of all codes will be in the appliance manual

D codes relevant to this fault finding guide

### 1<sup>st</sup> level diagnostic

D3=DHW Actual Flow temp. (situated on right hand side of Actostor)

D4=DHW storage temp (situated in middle of Actostor)

D6=DHW Target temp set point

D7=Warmstart/Storage target set point

D12=Shift load pump energised (100=energised 0=not energised)

D35= diverter valve position (read only) 0 = CH, 1 = DHW, 2 = Mid-position frost protection

D36=L/min flow

D76=dsn=8 (read only)



### 2<sup>nd</sup> level diagnostic

D70=setting the diverter valve (position0 = normal (factory setting), 1 = centre position, 2 = permanent heating)

D92=recognition of shift load storage tank(read only)

D93=dsn=8 used to change

A list of all codes are in the appliance manual



Tank module PCB Wiring connections

- 1 → Neutral
- 2 → 22VDC Shiftload pump dropping to 0VDC Average = 17VDC
- 3 → DHW Flow NTC 3.7 VDC Dropping on temp rise (Left hand side)
- 4 → Storage Tank NTC 3.7 VDC Dropping on temp rise (Middle)
- 5 →
- 6 → Inlet sensor NTC 3.7 VDC (Right hand side)
- 7 → Aquasensor 4.6 VDC Stationary, 2.4 VDC Spinning
- 8 → 4.6 VDC supply to aquasensor
- 9 → 5 VDC connection from main PCB X31
- 10 → 22.5 VDC connection from main PCB X31